



GeoMetrix Centerpoint Kit

Product Parts

12 Quad Frame
Banner B
Banner C (x5)
Banner D (x2)
Banner E
Banner G




Display Set-up


Purchased Kits are packaged with graphic banners already attached.

To display your Geometrix Kit, carefully expand the spring-loaded Frame.

To secure the display, connect the single latch on each side of the Frame to the receiving hub as shown.




Graphic Banner Placement



Attach Graphic Banners to the Frame by hanging their corner (or side) button holes on the Frame's pins. Multiple Banner holes will usually occupy one pin. Many Banner types attach to pins on both the front and back of the Frame.

Each banner type is designed to attach to the Frame at specific, predetermined angles, shown here:



Storage and Care

Carefully collapse the Frame, put it in the carrying case and store in a cool, dry place (you may leave the graphic banners attached).

To clean non-graphic hardware, wipe with a damp cloth.

Wash graphics on a gentle, cold cycle and machine dry with no heat. **Do not dry clean or iron.**